

Anywhere Map SEPTA Quick Start

Direct To Finder: Search utility for airports, nav aids, fixes/intersections, and user waypoints.

Emergency Mode: Single tap to enter E-mode then pick airport and activate emergency decent VNAV.

Pocket Plates®: Displays geo-referenced approach plates, arrivals and departures.

Find Nearest: Quick list closest airports, nav aids, fixes, SEPTA center, AWOS, cheapest fuel, etc.

Flight Plan Manifest: Full details of flight legs, save/load flight plan, Route Wizard, or clear an existing flight plan.


Flight Calculator: Calculate density altitude, true air speed and winds aloft.

Personal Digital Copilot: Set up reminders to switch fuel tanks, lower gear and begin descent.

Views: Quickly select and modify preset map display configurations.

WX Settings: Show/hide XM WX items from the map display.

Zoom/Backlight settings: Preset zoom levels, backlight adjustment and night/day toggle.



Toolbar show/hide toggle: Show/hide left and right toolbars on edges of map screen.

Tools: Leaves map screen for setup of aircraft profiles and advanced functions including XM WX.

www.anywheremap.com

© 2011 Control Vision Corp.

v1.0



The "Flight Plan" button will open the manifest of this plan.

Wpt	Rng	ETE	CRS	Air Spd'	VNAV
aKPTS					
aKCNU	38	00:23	290	100	Direct KCNU
aKMCI	104	01:03	20	100	Delete WP
Total	142	NM			Hold
ETE	01:25				Next WP
Wind	0KT from	000 deg.			Winds
	Fuel	13.8 gal			Done

Sample Flight Plan

Starting at Lakeland, Let's fly to Cross City (KCTY). The most important button on the SEPTA is the Direct To Finder, in the upper left corner. Use this button to create and modify flight plans.



1. Tap the Direct To Finder button, then tap the small white box that says "Enter Identifier..." The on-screen keyboard will appear.



2. Tap C then T, notice that KCTY is listed in the list. Either tap Y or tap KCTY in the list.
3. The search screen says Cross City, now tap "Direct To" to create a new flight plan. You have just created a flight plan from the current GPS location to KCTY. It will now show on the screen.



Return Button

Returns you directly to the main Map screen.



About Button

Displays the version of Anywhere Map software you're using along with the effective dates of the 28 day GPS mapping data installed.



Exit Button

The exit button can be found by tapping on the "Tools" icon then choose "Settings". This closes the Anywhere Map software when you're done flying and ready to use the street navigator.

VERY IMPORTANT: Only use the supplied charger to power your SEPTA. NEVER USE A MINI USB CHARGER. The USB port is for data only. Use of other chargers will not charge the SEPTA and could potentially cause damage.